QUICK START GUIDE

motorola

MODELS:
FOCUS73,
FOCUS73-2

For a full explanation of all features and instructions, please refer to the User's Guide.

1. How to register your Camera to Hubble account

A. Connect to power supply.

1. Connect the Camera round plug to the Y-shaped Power/LAN cable connector.
2. Insert the power adapter plug into the Power Socket and connect other end of the power adapter to a suitable mains power socket.
3. The Camera turns ON, and the LED indicator will start flashing slowly after booting finish.

B. Install Hubble for Motorola Monitors App.

Download the Hubble for Motorola Monitors App from the App Store for iOS® devices or from the Google Play™ Store for Android ™ devices.

⚠ WARNING:

STRANGULATION HAZARD – In case this unit is being used to monitor infants or children, keep the unit and adapter cord more than 1 metre from the cot and out their reach.
Never place camera or cords within a cot or near a bed. Secure the cord away from children's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

As with any electrical device, supervision of your pet's usage should be exercised until your pet is acclimated to the product. If your pet is prone to chewing, we strongly recommend you keep this and all other electrical devices out of its reach.

C. View on Compatible Smartphones, Tablets and Computers.

Wi-Fi® Camera   Connect to Internet via Wi-Fi®   Compatible Viewing Devices

1. Run the Hubble for Motorola Monitors App on smartphones or tablets.
2. Follow the in-app instructions to create your Hubble for Motorola Monitors account.
3. Log in to your account on your compatible smartphone, tablet or via www.hubbleconnected.com/motorola/login on your PC to access your live camera stream.

Please take note of the following minimum system requirements:
Smartphones/Tablets: iOS 7, Android™ 4.2

PC (if used for viewing): Windows® 7, Mac OS® 10.7, Chrome™ 24, Internet Explorer® 9, Safari® 6, Firefox® 18, Adobe® Flash® 15, Java™ 7

2. How to mount your Camera on the wall

A. Fixing Mounting Plate on the wall.

1. Mark the position of the screw holes on the wall.
2. Drill 4 holes and hammer the drywall plugs (included) into the holes as needed.
3. Fasten the mounting plate on the wall with the 4 Philips head screws (provided).

B. Hanging the Camera unit on the Mounting Plate.

Place the 4 mounting slots of the camera base on to 4 catches on the mounting plate. Make sure the unit sits firmly on the mounting plate with the center holes of 2 parts lined up.

C. Secure the Camera Unit

Fasten the unit to the mounting plate at the center hole with the tamper-proof screw by the wrench key provided.

D. Connecting Power Supply for the Camera Unit

Insert the power adapter plug into the Power Socket and connect other end of the power adapter to a suitable mains power socket.

3. Customer Support

If you are experiencing any issues with your Motorola Wi-Fi® Outdoor Pet Video Camera, please visit the help section on our website www.motorola.com.

You can also contact our customer support teams
+44 (0) 844 557 0890 (UK only)
+44 (0) 8187 62092 (ROI)

motorola

CE