

BS7671: 2008. Requirements for Electrical Installations, IEE Wiring Regulations, Building Regulations Electrical Safety

Installation must be carried out by a Competent Person or, failing that, the local building control authority must be notified of the proposed work before commencement and the completed installation must be

The schematic should be read in conjunction with the Solar manual, the Underfloor heating Installation manual, any 'Product Data Sheets' and

All fused spurs must be fitted with 5 amp fuses unless otherwise stated.

Where live conductors are sleeved in a colour other than brown, coloured marker sleeves should be fitted at the ends of the wires to

When radiators are used in conjunction with underfloor heating, the parts shown must be fitted in order to give independent control.

connections are shown to equipment that is not supplied by Nu-Heat, this is for guidance only. In all such cases the supplier's installation information should be checked before fixing and connecting the

In line with the company policy of product development, Nu-Heat reserves the right to supply different components to those shown.

please contact Nu-Heat Technical, quoting your QR (system reference)

This drawing is not site-specific. The number and type of cylinders,

**Underfloor Heating Control System** W2BN<sup>1</sup>Ne - Electrical 2nd fix, Boiler system, EnergyPro cylinder, Programmable thermostats

Heathpark Industrial Estate | Honiton | Devon EX14 1SD