EURO PART.

A **SMART PART** OF EUROPART

USING THE EUROPART SEARCH FUNCTION

1. If you know the Europart part number, or part of it, enter it in the dedicated multi-functional search box.

EXAMPLE - you want 12-BS-03 Bosch Carbon Brush 12-BS-03 or 12BS03 takes you straight to it 12-BS- will take you to a Gallery View of all Bosch Carbon Brushes

Click on the part number required to go to -

- Price
- Availability
- Additional information, e.g. technical specifications, fitting instructions if available
- Associated items
- **2.** If you know the manufacturer original part number, or part of it, enter it in the dedicated multi-functional search box.

EXAMPLE - you want 154740 Bosch Carbon Brush 154740 will take you straight to 12-BS-03

1547 takes you to a range of choices containing the partial code: then just select the item required In BOTH cases, click on the part number required to find the desired information.

3. If you have a detailed description of the part, enter it in the dedicated multi-functional search box.

EXAMPLE - you want Bosch Carbon Brushes

Bosch Carbon Brush will take you to a Gallery View of all parts containing the words Bosch, Carbon and Brush in the product description and/or Bosch in the model fit database In this case, click on the part number required to find the desired information.

NOTE - The more detailed the description, the more refined your search will be e.g. If you search for 'carbon', approximately 600 results are shown. If you search for 'Bosch Carbon Brush', approximately 16 results are shown.

Tips

- **DESCRIPTION:** A common description (like PUMP) will help to refine your results. But if the description entered does not match ours, then you will not get a result.
- **BRAND:** Inserting the Brand required e.g. 'Bosch' will help to refine your results. Remember though, some parts are databased against their brand manufacturer, and not their badged brand. For example, type 'Hygena' for Diplomat searches.
- **MODEL:** Enter the model number of Appliance. If it has punctuation, e.g. hyphen, dash or slash, omit the punctuation; if no result, try with the punctuation included. If you do not have the full Model Number, use only the leading digits (see below).
- Manufacturer's original part number: If using a partial entry, use only the leading digits; for example in the case of 154740, 1547 will give a result, but 4740 will give only parts that begin with 4740.

When no results are found: A message will appear telling you this. Try reducing the amount of information in your search. If you still get no results please **contact us**.

UNDERSTANDING EUROPART PART NUMBERS

Europart employs a straightforward part number identification system. Europart part numbers are always a sequence of -

Two numbers representing the product group; followed by two letters representing the product brand; followed by two or more numbers identifying the unique part.

Occasionally letters are added at the end to indicate a variation in colour, genuine equivalent, manufacturer etc.

Examples

35-DY-08LV



35 - Denoting the product group, in this case 35 for Vacuum Hoses.

DY - Denoting the product brand, in this case DY for Dyson.

08 - Identifying this unique part as Europart DC07 Lavender End Hose Assembly.

LV - Identifying this unique part as a Lavender colour variant of 35-DY-08 Europart DC07 Hose Assembly.

12-BS-03A



12 - Denoting the product group, in this case 12 for Laundry/Vacuum Carbon Brushes.

BS - Denoting the product brand, in this case BS for Bosch.

03 - Identifying this unique part as Bosch Motor Carbon Brushes (Pack of 2, 12.3mm x 4.8mm x 31mm).

A - Identifying this unique part as a genuine equivalent to 12-BS-03 non-genuine carbon brushes.

53-UN-38



53 - Denoting the product group, in this case 53 for Refrigeration Parts & Accessories.

UN - Denoting the product brand, in this case UN for Universal.

38 - Identifying this unique part as Universal Chest Freezer Hinge



EURC PART.

A **SMART PART** OF EUROPART

Product Groups

In order to assist you in identifying the correct Europart part number, below are the lists of product groups and the number used to classify those product groups which are used as the first two digits of any part number.

Product Group	Appliance	Description
03	Home Laundry / Vacuum Cleaner	Armatures
04	Vacuum Cleaner	Bearings
05	Washing Machine	Bearings & Bearing Kits
07	Vacuum Cleaner	Belts
08	Washing Machine	Belts
09	Tumble Dryer	Belts
10	Vacuum Cleaner	Brushbar Agitator & Parts
11	Home Laundry / Vacuum Cleaner	Capacitors
12	Home Laundry / Vacuum Cleaner	Carbon Brushes
13	Home Laundry / Vacuum Cleaner	Clutches
14		Cooker & Cooker Hood Parts
15	Home Laundry / Vacuum Cleaner	Fittings & Covers
16	Dishwasher / Washing Machine	Dispensers
17	Tumble Dryer / Washing Machine	Doors & Rims
18	Tumble Dryer / Washing Machine	Door Boot, Seals & Gaskets
19	Tumble Dryer / Washing Machine	Door Handles, Hinges & Latches
21	Vacuum Cleaner	Cloth Bags
22	Universal / Vacuum Cleaner	Cables
23	Universal	Electrical Connectors & Parts
24	Vacuum Cleaner	Extension Rods & Bent Ends
25	Home Laundry / Vacuum Cleaner	Fans
27	Vacuum Cleaner	Filters
28	Washing Machine	Filters
29		Food Mixer & Processor Parts & Accessories
30		Fire Safety Appliances
31	Vacuum Cleaner / Washing Machine	Gaskets & Seals
32	Universal	Garden Appliances Parts & Accessories
33	Vacuum Cleaner	Handles
34	Home Laundry	Heaters & Elements
35	Vacuum Cleaner	Hoses
36	Vacuum Cleaner	Hose Ends
37	Home Laundry	Hoses & Condensers
38	Home Laundry	Hose Connectors
40	Home Laundry	Knobs & Parts
41	Universal	Lamps & Bulbs
42	Home Laundry / Vacuum Cleaner / Commercial	Motors & Parts



EURO PART.

A **SMART PART** OF EUROPART

Product Group	Appliance	Description	
43	Home Laundry	Mountings & Suspension Parts	
46	Vacuum Cleaner	Paper & SMS Bags & Accessories	
47		Polisher Parts & Accessories	
48	Home Laundry	Pressure Switches	
50	Home Laundry	Pulleys & Solenoids	
51	Home Laundry / Commercial	Pumps	
52	Home Laundry	Pump Parts	
53		Refrigeration Parts & Accessories	
54	Home Laundry	Drum Oil Seals	
55		Service Parts & Accessories	
57	Home Laundry	Shafts & Gearboxes	
58		Shaver Parts & Accessories	
59	Home Laundry	Spin Mats	
60	Home Laundry / Vacuum Cleaner	Springs, Nuts & Bolts	
61	Vacuum Cleaner	Switchgear	
62	Universal / Home Laundry	Interlocks & Switchgear	
64		Plumbing Parts & Accessories	
65		Small Appliance Parts & Accessories	
66	Home Laundry	Thermostats & TOC's	
67	Home Laundry	PCB Modules, Timers & Parts	
68		Dishwasher Parts	
69	Vacuum Cleaner	Floor Tools & Accessories	
70	Washing Machine / Tumble Dryer	Tubs, Drums, Lifters & Parts	
71	Dishwasher / Washing Machine	Solenoid Valves	
72	Tumble Dryer	Vent Hoses & Kits	
74	Washing Machine/Vacuum Cleaner	Wheels & Trolleys	
75		Microwave Parts & Accessories	
76		Finished Goods	
77		Steam Cleaner Parts & Accessories	
78		Janitorial Service Parts & Accessories	
79		Cookware & Barbeque Parts & Accessories	
80		Pressure Washer Parts & Accessories	

- ALL Cooker & Cooker Hood Parts (except for universal oven lamps and bulbs) come under section 14
- ALL Refrigeration Parts & Accessories come under section 53
- Most Dishwasher Parts come under section 68 however please also check in the respective sections for dishwasher parts e.g. section 67 for PCB Modules, Timers & Parts
- Home Laundry encompasses Dishwashers, Tumble Dryers and Washing Machines

This is a guide only. Occasionally parts do not fall under the correct or obvious product group, for example section 68 is generally for Dishwasher Parts but parts for dishwashers can sometimes be found under their respective product group e.g. a dishwasher inlet valve could be found under section 68 (Dishwasher parts) or section 71 (Dishwasher/Washing Machine Solenoid Valves). If you are in any doubt, refer to the part description or contact us.



EURO PART.

A **SMART PART** OF EUROPART

Brand Abbreviations

Below is a list of the brands and their corresponding two letter abbreviations which are used as the second two digits of any part number. This list is not exhaustive but it covers the most popular brands which Europart supply spares and accessories for.

Brand	Abbreviation	Brand	Abbreviation
AEG	AG, EL, ZN	Indesit	IN
Airflo	AF	Jeyes	JY
Alno	AG, EL, ZN	Karcher	KA
Aquavac	AQ, GB	Kenwood	KW
Ariston	AR	Kirby	KI
Bauknecht	BK	Lec	LC
Beko	ВО	LG	LG
Belling	BL	MFI / Diplomat / Hygena	HY
Bissell	BI	Miele	ML
Bosch/Siemens	BS	Morphy Richards	MR
Brandt	BT	Neff	NF
Burco	BC	New World	NW
Candy	CY	Nilco	NO
Cannon	CR	Nilfisk / Alto	NL
Creda	CR	Numatic	NM
Crosslee	CL	Panasonic	NT
Daewoo	DW	Philco	BN
De Dietrich	DD	Philips	PS
DeLonghi	DL	Prestige	PR
Dirt Devil	DD	Proline	PL
Dyson	DY	Rowenta	RW
Electrolux	EL	Samsung	SG
Fagor	FG	Sebo	JY
Flavel	FL	Servis	SV
General Electric	GE	Smeg	SM
GHD	GD	Teba	ТВ
Glen Dimplex / Stoves	ST	Tefal	TF
Haier	HA	Tricity Bendix	TY
Hitachi	HT	Vax	VX
Homark	HM	Vorwerk	VW
Hoover	HV	Whirlpool	WP
Hotpoint	HP	White Knight	CL, PS
Ignis	IG	Zanussi	ZN, EL
Universal Parts & Accessories	UN	Vacuum Bags	VB
		Vacuum Motors	VM

This is a guide only. Occasionally parts do not fall under the correct or obvious brand abbreviation e.g. Zanussi may fall under ZN or EL as Zanussi is an Electrolux brand. If you are in any doubt, refer to the part description or contact us.

